

The President

- INSTALLATION
- OPERATION
- MAINTENANCE

Meyer Machine & Equipment, Inc.
351 Main Street
Antioch, Illinois 60002

(800) 728-3828
(847) 395-2970
(847) 395-2972 Fax

The President

I.O.M. MANUAL

Safety :

- Do not operate this equipment until you have read this manual and fully understand the machines' operation.
- Never operate the vacuum without a hose on the inlet.
- Never operate the vacuum without a hose or bag on the discharge of the fan housing.
- Never place your hands, arms or any body parts near the fan inlet or discharge while the fan is in motion. The fan can cause severe and permanent injuries to bodily parts.
- Never attempt any maintenance while the fan is rotating.
- Prior to any maintenance, turn the key to the off position and remove the key from the ignition. Then remove the wire from the spark plugs. This will eliminate the possibility of accidental ignition.
- Never touch the positive and negative leads of the battery. This is a 12 volt Direct Current negative ground system.
- Exercise caution when moving your vacuum up & down ramps. This machine weighs in excess of 1,200 lbs. and can cause injury if moved improperly.
- Do Not touch the muffler. The engine on the vacuum produces an extremely hot exhaust system and can cause severe burns if touched.
- Do Not transport the vacuum without properly securing the vacuum in your vehicle.

WARNING:

- **Do Not continue to operate a vacuum that has an out of balance condition. This will be apparent by the machine shaking violently. Operating a machine that is out of balance could result in damage to the machine or injury to the operator.**

The President

I.O.M. MANUAL

Installation :

Upon receipt of your power vacuum and equipment, double check your packing list against the actual materials received. Note any discrepancies and/or damage to the freight on the trucker's freight bill. Any claims will have to be processed through the freight company and they will require documentation.

Unpack your **President** power vacuum using caution not to damage the machine. Your machine should be fully assembled with the exception of the gas tanks and filter bag. Locate the packing slip attached to your shipment; check to see that you received everything that is listed.

Locate the gas tank. Attach the fuel lines to the quick couplers mounted on the fuel tank after the vacuum has been positioned properly at the job site. Connect your filter system to the vacuum. The Vacuum is now ready to run.

Warning: Make sure fuel line and fuel tank are placed away from the muffler to minimize the chance of fire.

Note: Check the oil in the engine prior to starting the engine. See the engine Owner's Manual for these instructions.

The President

I.O.M. MANUAL

Operation :

Prior to operating your **President** power vacuum, there are a few necessary points that must be checked.

- Check oil level
- Inlet hose is firmly in place
- Discharge bag/hose is clamped on
- Machine is located in a well ventilated area

NOTE: Never operate your vacuum without proper inlet and discharge connections.

Once you have checked the items above, you are ready to proceed with starting the vacuum.

Place the throttle knob to the low speed setting, make sure the clutch is disengaged, and crank the engine until it starts. Let the engine idle for 2-3 minutes then engage the clutch. Once the clutch is engaged adjust the throttle knob to bring the vacuum up to operating speed.

We define "operating speed" as the speed that is necessary to effectively do the job. If the job is small, then the throttle need not be moved to the maximum setting. On larger jobs you will need to increase the speed to achieve the proper vacuum level.

NOTE: Engage or disengage the clutch at idle speed only!!

When the vacuuming job is done, do not remove the inlet hose or the discharge bag or hose until the machine has been slowed to an idle, the clutch has been disengaged, the key is turned off & the vacuum has come to a complete stop.

To shut down the vacuum, gradually move the throttle knob to idle, disengage the clutch, then turn the key to the off position.

NOTE: All warranty repairs must go through Meyer Machine & Equipment prior to any service work being done. Work not authorized by Meyer Machine & Equipment will not be covered under warranty.

The President

I.O.M. MANUAL

Maintenance :

Your **President** power vacuum, as well as the rest of your equipment, will last for many years if you properly maintain the equipment.

The **President** requires the following regular maintenance procedures:

NOTE: ALWAYS FOLLOW THE SAFETY GUIDELINES AS OUTLINED ON PAGE 1 OF THIS MANUAL.

- I. Every day check the oil level by removing and checking the dip stick. Refer to the accompanying Kohler Owner's manual for the proper oil viscosity.
- II. The engine should have the oil and filter changed every 100 hours of operation. Drain the oil from the extended oil drain on the side of the engine opposite the muffler. Then refill the oil reservoir with the oil recommended in the accompanying Kohler Owner's manual.
- III. The bolts on the fan wheel should be checked for tightness every time you change your oil. This requires a ½" Dia. socket wrench with an extension. Locate the (3) bolts on the bushing inside the fan inlet. Then turn each bolt clockwise until they are tight.
- IV. The air filter on the engine should be checked every 50 hours of operation. To do this, loosen the air cleaner clamp and remove the cover. Remove the air cleaner and take the pre-filter off the pleated air filter. Wash this filter off allow it to dry and then replace the pre-filter. When you maintain the pre-filter you will not have to replace the main filter as often.
- V. The engine will also require other maintenance as outlined in the accompanying Kohler Owner's Manual.
- VI. The fan wheel should be checked every 1,000 hours or, at a minimum, once per year. Remove the fan wheel and visually inspect it for mechanical integrity. If any aberration is detected, the fan wheel should be replaced immediately.